



## 配管接頭(E) Piping Adapter



- 即使配管不取下，機器也能夠進行裝卸，並且容易維修。
- A piping adapter allows installation / removal of the component without removing the piping and thus makes maintenance easier.




Type	Port Size	A	B	C	適用機種 Applicable model
E300-04	G 1/2"	29	29	28.2	PC3000, PF3000, PR3000, PW3000, PL3000
E400-10	G 1"	40	43	40.2	PC4000, PF4000, PR4000, PW4000, PL4000


## 2通口分歧塊(Y) Cross Spacer



- 上、下皆可進行分歧配管。
- Make it possible to diverge piping in up / down directions.



### Y32-02



### Y42-04

